

MSA Gland Nut Installation Wrench for Koni Struts

Tools Required:

- 1) MSA Gland Nut Wrench (included)
 - 2) Foot-Pound specific Torque Wrench
 - 3) 3/8" to 1/2" Adapter**
 - 4) Second set of hands*
- (**Only needed if using a 3/8" drive Torque Wrench)

Instructions:

- 1) Tighten the gland nut as far as possible by hand.
- 2) Insert your torque wrench into the right side of the gland nut wrench from the top as shown below (after installing the adapter if needed), then align the two posts of the wrench into the gland nut.
- 3) Torque to 89 ft-lbs. Depending on how far you were able to install the nut before using the tool, you may need to remove the tool and rotate it to reach the correct spec. *A second set of hands can help keep the tool in position during installation, especially if you have not used this style of tool before.

Note: Hang on to this tool! In the event that the cartridges need to be removed in the future, this tool can be used in reverse (from the left side and turned counter-clockwise).

